



Using a Tactrix with Windows

Atlas uses its own built-in device driver for the Tactrix OpenPort 2.0. When using Atlas with a Tactrix in a Microsoft Windows environment, the adapter should appear in Device Manager as a **Communications Port (COM*)** under the **Ports (COM & LPT)** device category.



Atlas will not be able to successfully communicate with the adapter if it appears under the **Vehicle PassThru Interfaces** category as a **Tactrix Openport 2.0 J2534 Vehicle Interface**.



The Tactrix drivers must be uninstalled in order to proceed.

Driver Removal Steps

1. Right click on **Tactrix Openport 2.0 J2534 Vehicle Interface**
2. Select **Properties**
3. Click the **Driver** tab in the Properties window
4. Select **Uninstall Device**
5. Restart your PC upon uninstaller completion

Revision #10

Created 27 January 2025 14:11:32 by JoanOfHill

Updated 27 January 2025 16:46:43 by JoanOfHill