


# Reverting to Another Calibration


If you would like to revert your changes in the current calibration to another calibration, you can always **Apply a different calibration** by clicking *Edit -> Apply different calibration...*



The screenshot shows the Ignition software interface with the 'Edit' menu open. The 'Apply different calibration...' option is highlighted. The background displays a table of RPM values and corresponding calibration data.

RPM	0.78	0.94	1.09	1.25	1.56	1.88	2.03	2.19	2.34
400	0.00	11.50	4.00	-2.00	-2.00	-4.00	-4.50	-5.50	-8.00
800	12.50	5.00	-1.50	-2.00	-4.00	-4.50	-5.50	-8.00	-8.00
1000	28.00	25.00	21.00	16.00	13.00	5.50	0.00	-2.00	-4.00
1100	28.50	25.50	22.00	16.50	13.00	6.00	1.00	-2.00	-4.00
1200	31.00	31.00	27.50	21.50	16.50	9.50	6.50	2.00	1.00
1400	32.00	31.00	28.00	22.50	16.50	11.50	7.50	2.50	-0.50
1600	33.00	32.00	28.50	23.00	17.00	12.00	8.50	4.50	-0.50
1800	33.50	32.50	0.00	0.00	0.00	0.00	6.50	2.00	-1.00
2000	33.50	33.00	0.00	0.00	0.00	0.00	9.50	4.00	1.00
2200	33.50	33.00	0.00	0.00	0.00	0.00	10.50	4.50	1.00
2400	34.00	34.00	0.00	0.00	0.00	0.00	12.00	7.50	2.00
2800	38.00	34.00	0.00	0.00	0.00	0.00	13.00	8.00	3.50
3200	38.00	34.00	0.00	0.00	0.00	0.00	15.00	9.50	4.50
3600	38.00	34.00	0.00	0.00	0.00	0.00	17.00	11.00	6.50
4000	38.00	34.00	0.00	0.00	0.00	0.00	18.00	12.00	6.50
4400	38.00	34.00	0.00	0.00	0.00	0.00	18.50	13.00	7.50
4800	38.00	34.00	31.00	27.50	25.00	22.00	19.50	18.50	14.00
5200	38.00	34.00	31.00	27.50	25.50	23.50	20.00	19.00	14.50
5600	38.00	34.00	31.00	29.00	26.00	24.00	21.50	20.00	14.50
6000	38.00	34.00	31.00	29.00	26.00	24.00	21.50	20.50	14.50
6400	38.00	34.00	31.00	29.00	26.00	24.00	21.50	20.50	14.50
6800	38.00	34.00	31.00	29.00	26.00	24.00	21.50	20.50	14.50

The default selection in the **Select Calibration** dialog box will always be the **Base Calibration** you set for the current calibration, if applicable, for faster reverting:



The calibration will be updated. Note that only **selected cells** will be changed. In this case, **Ctrl/Cmd+A** was used to select the entire table before the operation took place:

		Load (g/rev)											
RPM		0.16	0.31	0.47	0.63	0.78	0.94	1.09	1.25	1.56	1.88	2.03	2.19
	400	27.00	24.00	19.00	16.00	11.50	4.00	-2.00	-2.00	-4.00	-4.50	-5.50	-8.00
	800	27.00	24.00	19.00	16.00	12.50	5.00	-1.50	-2.00	-4.00	-4.50	-5.50	-8.00
	1000	28.00	25.00	21.00	16.00	13.00	5.50	0.00	-2.00	-4.00	-4.50	-5.50	-8.00
	1100	28.50	25.50	22.00	16.50	13.00	6.00	1.00	-2.00	-4.00	-4.50	-5.50	-8.00
	1200	31.00	31.00	27.50	21.50	16.50	9.50	6.50	2.00	1.00	-2.50	-3.50	-6.00
	1400	32.00	31.00	28.00	22.50	16.50	11.50	7.50	2.50	-0.50	-2.50	-3.50	-6.00
	1600	33.00	32.00	28.50	23.00	17.00	12.00	8.50	4.50	-0.50	-3.50	-3.50	-6.00
	1800	33.50	32.50	30.00	25.00	20.00	14.50	9.00	6.50	2.00	-1.00	-3.00	-4.50
	2000	33.50	33.00	31.00	26.50	22.00	16.50	13.00	9.50	4.00	1.00	-1.00	-3.50
	2200	33.50	33.00	31.00	26.50	22.00	18.00	14.00	10.50	4.50	1.00	-0.50	-3.00
	2400	34.00	34.00	31.00	26.50	22.50	19.00	14.50	12.00	7.50	2.00	0.50	-2.00
	2800	38.00	34.00	31.00	27.00	23.50	20.00	17.00	13.00	8.00	3.50	1.00	0.00
	3200	38.00	34.00	31.00	27.00	23.50	20.50	19.00	15.00	9.50	4.50	2.00	1.50
	3600	38.00	34.00	31.00	27.00	24.00	21.00	19.00	17.00	11.00	6.50	4.00	2.50
	4000	38.00	34.00	31.00	27.00	24.00	21.00	19.00	18.00	12.00	6.50	4.00	3.00
	4400	38.00	34.00	31.00	27.50	25.00	21.50	19.00	18.50	13.00	7.50	4.50	4.50
	4800	38.00	34.00	31.00	27.50	25.00	22.00	19.50	18.50	14.00	8.50	6.50	5.00
	5200	38.00	34.00	31.00	27.50	25.50	23.50	20.00	19.00	14.50	9.50	8.00	5.00
	5600	38.00	34.00	31.00	29.00	26.00	24.00	21.50	20.00	14.50	10.00	8.00	6.50
	6000	38.00	34.00	31.00	29.00	26.00	24.00	21.50	20.50	14.50	10.00	7.50	7.00
	6400	38.00	34.00	31.00	29.00	26.00	24.00	21.50	20.50	14.50	10.00	7.50	7.00
	6800	38.00	34.00	31.00	29.00	26.00	24.00	21.50	20.50	14.50	10.00	7.50	6.50